

Technical Information — Sizes

Stair Nose



The Landing Stair Nose combines style and function to enhance the beauty of a staircase or step. **Available as Standard or Moisture Resistant.**

Surface Material: High Wear Resistant Aluminum Oxide Laminate

Core Material:

Standard Stair Nose: Moisture Resistant MDF

Moisture Resistant Stair Nose: Exterior Grade Composite Wood Product




Versatrim Shim

Use one to raise the Stair Nose when used for a 12 mm floors and two for 15 mm Floors

Material: Standard HDF


Installation

8 mm Floors




12 mm Floors

Use Versatrim Shim for 12 mm floors.




Stair Nose

Installation WITHOUT using Shim for floors from 8 mm in thickness. Glue Down/No Screws **8 mm Floors**



Step 1

Install the riser flush to the stair. Use the Stair Nose to determine where to start your flooring. The Stair Nose must fit snugly next to plank & riser. Remove Stair Nose and **glue the flooring plank down.**




Step 2


Generously apply **Versatrim's Molding Adhesive*** to the bottom of the Stair Nose. Make sure Stair Nose sits tightly against the stair riser. Once it's in place, press it firmly down. **Allow to fully cure for 24 hours before traffic.**



Installation using Shim for floors 12 mm in thickness. Glue Down/No Screws in Stair Nose




12 mm Floors




Step 1

Install the riser flush to the stair. Use the Stair Nose and Shim to determine where to start your flooring. The Stair Nose must fit snugly next to plank & riser. Remove Stair Nose & Shim and **glue the flooring plank down.**



Step 2

Apply a generous amount of **Versatrim's Molding Adhesive*** to the shim and secure it flush to the staples, nails, or countersunk screws.



Step 3

Generously apply **Versatrim's Molding Adhesive*** to the bottom of the Stair Nose. Make sure Stair Nose sits tightly against the stair riser and shim. Once it's in place, press it firmly down. **Allow to fully cure for 24 hours before traffic.**



* For more information, go to: versatrim.com/molding-adhesive